

configuration could offer a simple picture for dynamical measurements, but has the disadvantage of showing a rather low sensitivity and of being based on the use of strong laser fields, which can significantly perturb the probed molecule.

3 Time-resolved photoelectron circular dichroism

The resonance-enhanced multiphoton ionization of fenchone studied above was carried out through the excitation of Rydberg states around 6.1 eV. We conducted time-resolved measurements to follow the ultrafast relaxation of these Rydberg states and to investigate the sensitivity of PECD as a probe of the molecular dynamics. After summarizing the results of our first pump-probe study in which we used a single photon process for both the pump and probe steps,¹ we investigate the case of multiphoton absorption.

3.1 Single photon excitation and single-photon ionization

The first (3s) Rydberg states of fenchone lie slightly above 6 eV (Fig. 7). We thus generated the fourth harmonic of our 800 nm pulses to produce 6.17 eV (201 nm) pulses with 30 meV bandwidth and $\sim 2 \mu\text{J}$ energy. The pulses were linearly polarized, and were focused around $5 \times 10^{11} \text{ W cm}^{-2}$ by a lens into the VMIS.




Fig. 7 Pump and probe configuration for time-resolved photoelectron circular dichroism in fenchone molecules. The right panel shows the highest-occupied and 3s Rydberg state molecular orbitals.